



STANDARD TIE WIRE DETAIL

Alternating single and double half hitches (locked loops)
(See Note 2)




SPIRAL BINDER LACING



STANDARD SPIRAL BINDER


(See Note 2)



BEFORE CLOSURE

AFTER CLOSURE

INTERLOCKING FASTENER



BEFORE CLOSURE

AFTER CLOSURE


OVERLAPPING FASTENER

ALTERNATIVE GABION JOINT MATERIAL FASTENERS


(Fastener dimensions nominal)
(See Note 3)

To Assemble Transitional Gabion Basket:

- Step ① Cut mesh along joint between Front Panel and Base Panel.
- Step ② Unfasten End Panel "A" from Base Panel and rotate End Panel "A". Fasten End Panel "A" to Back Panel.
- Step ③ Fold the cut portion of the Base Panel into upright position along diagonal from the diaphragm to the corner of the Back Panel.
- Step ④ Fold the Back Panel, Front Panel and End Panel "B" into upright positions. Fasten End Panel "B" to the Back Panel and the Front Panel.
- Step ⑤ Rotate End Panel "A" and the cut portion of the Front Panel inward against the upturned portion of the Base Panel. Fasten along the overlapped portion of the Front Panel and End Panel "A". Fasten the overlapped portion of the Front Panel and End Panel "A" to the folded upright portion of the Base Panel along the diagonal (described in Step 3).
- Step ⑥ Fill the Transitional Gabion Basket with rock as per specifications.
- Step ⑦ Close lid and fold over corner of Lid Panel. Fasten along Lid Panel edges.



FLAT LAYOUT OF GABION BASKET



ASSEMBLED TRANSITIONAL GABION BASKET

TRANSITIONAL GABION BASKET

(For 6'-0", 9'-0" or 12'-0" gabion)

STATE OF CALIFORNIA
DEPARTMENT OF TRANSPORTATION

GABION BASKET DETAILS No. 2

NO SCALE

D100B

DIST	COUNTY	ROUTE	POST MILES TOTAL PROJECT	SHEET NO.	TOTAL SHEETS

REGISTERED CIVIL ENGINEER

May 31, 2018

PLANS APPROVAL DATE

THE STATE OF CALIFORNIA OR ITS OFFICERS OR AGENTS SHALL NOT BE RESPONSIBLE FOR THE ACCURACY OR COMPLETENESS OF SCANNED COPIES OF THIS PLAN SHEET.

REGISTERED PROFESSIONAL ENGINEER
Bruce D. Swanger
No. C61257
Exp. 6-30-19
CIVIL
STATE OF CALIFORNIA

NOTES:

1. A joint connection must be made where any panel edge meets another panel. This includes adjacent gabion baskets, individual panels within a basket, diaphragm edges, etc.
2. Standard tie wire may be used as a joint connector for either twisted or welded mesh. Spiral binder is to be used with welded mesh only.
3. When alternative gabion joint material fasteners are not capable of enclosing all wires along a joint, especially at Basket-To-Basket Joints, either standard tie wire or spiral binder, as applicable, must be used.